



The net enclosure is an important safety device, ensure correct assembly. One person can assemble the net, it is easier with 2 people though. Do not rush, some patience may be required.

ATTACHING THE SAFETY NET ENCLOSURE



Step 1

This procedure assumes your net poles, net pole foams and top net pole caps are intact and are still assembled on your trampoline. Net fitment can be made easier if the net poles are loosened off to allow for some more wriggle room and retightened once the net is fitted.



Step 2

Position the net onto the trampoline and line up where you want your entrance to be. The sleeves go to the outside (netting on the inside)

NOTE: you can also adjust where the entrance is at the end of the assembly by picking up and rotating the trampoline.



Step 3

Working from the top of the net poles slide the net sleeves down, work your way around the trampoline and gradually work the sleeves down approximately 100 to 250mm at a time until all net sleeves are fully down to the trampoline frame. Make sure the net pole foams are fully up to the top of the net pole sleeve.



Step 4

Using the net clips at the bottom of the net, fasten the net to the corresponding V-ring on the mat; by going under the padding from the outside of the frame.



Step 5

If you have loosened off any net poles for step 8.1 then retighten up.